

7 SUMMER CARE TIPS FOR YOUR LIGHTSPEED SYSTEM

As the school year comes to a close, make sure you follow these easy steps to power down and protect your Lightspeed system over the summer.

1



Charge the microphone and any pod batteries fully after the last day of use.

2



Remove the microphones and any pods from the charger.

3



Unplug your systems from the wall power outlet.

4



Put the room number on all systems, mics, and power cords and **store together** in a safe place. (Ziploc plastic bags work well!)

5



Extended storage temperature should be less than 100 degrees and 95% humidity. We do not recommend electronic equipment in outdoor containers without climate control.

6



The batteries will hold a residual charge over the summer, and will only need to be charged overnight before the first day of use.

7



Cover the amplifier to **protect the components** from summer construction / renovation.